

## Lab-Tips® - LT01465

### Long Handle Open Cell Foam Swab

Cleanroom laundered 100 ppi reticulated foam sock head swab

The LT01465 foam swab with long handle is specially suited for cleaning hard to reach areas. Its cleanroom laundered open cell foam tip is exceptionally clean and soft with excellent sorbency. A flexible internal head paddle and handle allow for added

dexterity. This swab may replace cotton long handled swabs in applications requiring minimal contamination levels.



#### Key Attributes

- Cleanroom laundered polyurethane foam over flexible paddle head
- 100 ppi open cell foam
- Thermally bonded head
- Laundered and packaged in Class 10 (ISO Class 4) cleanroom

#### Benefits

- Low particles, fibers, ions and extractables
- Good chemical resistance
- No contaminating adhesives
- Good sorbency and excellent solvent hold
- Free from Silicone, Amides and DOP

#### Environmental

- Complies with RoHS and REACH requirements

#### Applications

- Designed for the highest level of contamination control in critical processing applications
- Cleaning of sensitive equipment
- Applying lubricants and other liquids
- Removing excess materials

#### Other Clean Foam sock tip swabs

- LT070P Pointed swab
- LT070R Small handle rigid head swab
- LT070F Small handle flexible head swab

#### Physical Characteristics

<b>Head Material</b>	Open Cell Foam	<b>Handle Thickness</b>	3.1mm {0.122"}
<b>Head Width</b>	7mm {0.276"}	<b>Handle Length</b>	145mm {5.71"}
<b>Head Thickness</b>	3mm {0.118"}	<b>Total Swab Length</b>	162mm {6.38"}
<b>Head Length</b>	16.8mm {0.661"}	<b>Head Bond</b>	Thermal
<b>Handle Material</b>	Polypropylene	<b>Handle Text</b>	Berkshire
<b>Handle Width</b>	3.1mm {0.122"}		

[www.berkshire.com](http://www.berkshire.com)

Contact: Tel 1 800 242 7000

[info@berkshire.com](mailto:info@berkshire.com)

Americas	Tel 1 413 528 2602	Fax 1 413 528 2614	<a href="mailto:info@berkshire.com">info@berkshire.com</a>
Europe	Tel 44 (0) 870 757 2877	Fax 44 (0) 870 757 2878	<a href="mailto:enquiries@berkshire.uk.com">enquiries@berkshire.uk.com</a>
SE Asia	Tel 65 6252 4313	Fax 65 6252 4312	<a href="mailto:enquiries@berkshire.com.sg">enquiries@berkshire.com.sg</a>
Japan	Tel 81 3 5827 2380	Fax 81 3 5827 2382	<a href="mailto:master@berkshire.co.jp">master@berkshire.co.jp</a>

## Technical Data:

ATTRIBUTE		LT01465	TEST METHOD
Non-Volatile Residue	IPA mg/swab	0.094	IEST-RP.CC004.3, Sec 7.1.2
Ions (µg/swab)	Chloride	0.023	IEST-RP.CC004.3, Sec 7.2.2
	Sulfate	0.024	
	Nitrate	ND*	
	Phosphate	ND*	
	Fluoride	ND*	
	Potassium	0.0033	
	Calcium	0.022	
	Sodium	0.050	
	Magnesium	0.0019	

## Notes:

- Data shown are typical values
- Due to differences in test methods applied and equipment utilized by different swab manufacturers, valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions.
- \* ND\* = below the detection limit of the equipment.

## Order Information:

Product	Item Number	Size	Swabs/pk	Pks/cs	Case size
Long Handle Foam	LT01465.10	162mm	100	10	180 x 150 x 170mm


## Other Berkshire Products



Wipers




Mop Systems



Face Masks



Glove Liners



Documentation Systems



Swabs